



16208982

## Rocker, S.1/B.3/B.7, white glossy

## **Technical properties**

| Controls and | indicators |
|--------------|------------|
|--------------|------------|

| Push-buttons                     | also for KNX applications: push-button, 1gang, and<br>group push-button, 1gang |
|----------------------------------|--|
| Rocker switch/rocker push-button | for rocker push-buttons ; for change-over/interme-<br>diate switch             |
| Materials                        |  |
| Colour of design line            | white  |
| Colour                           | white  |
| Colour                           | white  |
| Surface appearance               | glossy   |
| Installation, mounting           |  |
| Installation mode                | clamp fastening  |
| Use cases                        |  |
| Application                      | Light control  |
| Safety                           |  |
| REACH conform                    | Yes  |
| RoHS conform                     | Yes  |
| Halogen free                     | Yes  |
| Identification                   |  |
| Application, usage               | Light control ; KNX - operating systems  |
| Main design line                 | Berker S.1/B.3/B.7   |
| Secondary design line(s)         | Berker S.1 ; Berker B.3 ; Berker B.7   |