



11248982

### Centre plate for push-button/pilot lamp E10, S.1, white glossy

#### Technical properties

##### Dimensions

|           |         |
|-----------|---------|
| Cut-out Ø | 27.2 mm |
|-----------|---------|

##### Materials

|                       |        |
|-----------------------|--------|
| Colour of design line | white  |
| Colour                | white  |
| Colour                | white  |
| Surface appearance    | glossy |

##### Installation, mounting

|                   |                                 |
|-------------------|---------------------------------|
| Installation mode | centre plate for plug-in fixing |
|-------------------|---------------------------------|

##### Use cases

|             |               |
|-------------|---------------|
| Application | Light control |
|-------------|---------------|

##### Safety

|               |     |
|---------------|-----|
| REACH conform | Yes |
| RoHS conform  | Yes |
| Halogen free  | Yes |

##### Identification

|                          |                                      |
|--------------------------|--------------------------------------|
| Application, usage       | Light control                        |
| Main design line         | Berker S.1/B.3/B.7                   |
| Secondary design line(s) | Berker S.1 ; Berker B.3 ; Berker B.7 |

##### Instructions

|                  |  |
|------------------|--|
| Information text | For push-buttons, LED and neon lamps and covers, see "Supplementary products". |
|------------------|--|