

WMV783N

1930 Knob for push-button and pilot lamp E10



- Installation, mounting
 - Imprint
 - without imprint
- Identification
 - Designation syntax: Main application
Push-button;pilot lamp E10
 - Designation syntax: Core designation/function
Push-button