

70 kA

65 kA



HEE970H

Moulded Case Circuit Breaker h1000 3P 70kA 1000A LSI

Technical properties

Technical properties	
Architecture	
Number of poles	3 P
Functions	
Complete device with protection unit	Yes
Trip Unit	LSI
Integrated earth fault protection	No
Configuration	
Number of modules	12
Main electrical features	
Rated operational voltage Ue	220 / 690 V
Frequency	50/60 Hz
Voltage	
Rated insulation voltage	800 V
Rated impulse withstand voltage	8 kV
With under voltage release	No
Electric current	
Rated current	1000 A
Rated ultimate short-circuit breaking capacity Icu under 690V AC IEC 60947-2	20 kA
Thermal protection nob setting xIN	0.4 / 0.5 / 0.63 / 0.8 / 0.9 / 0.95 / 1
Breaking capacity on 1 pole for IT 230V NF 60947-2	60 kA
Breaking capacity on 1 pole for IT 400V NF 60947-2	9 kA
Rated service breaking capacity lcs AC according IEC 60947-2	71 %
Rated ultimate short-circuit breaking capacity Icu under 230V AC IEC 60947-2	100 kA
Rated ultimate short-circuit breaking capacity Icu under 240V AC IEC 60947-2	100 kA
Rated ultimate short-circuit breaking capacity Icu under 400V AC IEC 60947-2	70 kA
Rated ultimate short-circuit breaking	

Current correction factors

capacity Icu under 415V AC IEC 60947-2

Rated ultimate short-circuit breaking capacity Icu under 440V AC IEC 60947-2

Correction factor of rating current for 2 devices placed side-by-side	1
Correction factor of rating current for 3 devices placed side-by-side	1
Correction factor of rating current for 4 and 5 devices placed side-by-side	1
Correction factor of rating current for 6 devices placed side-by-side	1
Power	
Total power loss under IN	186 W
Power loss per pole at In	62 W
Tripping	
Tripmode	LS
Thermal protection trip time	5 / 10 / 11 / 16 / 21 ms
Time of response when opening	10 ms
Electrical specifications	
Magnetic trip delay time	100 to 200 ms
Endurance	
Electric endurance in number of cycles	1000
Number of mechanical operations	4000
DIN rail mounting with optional adaptator	No
DIN rail mounting with optional adaptator Connection	
DIN rail mounting with optional adaptator Connection Type of connection	
DIN rail mounting with optional adaptator Connection Type of connection Settings	Termina / 8820 / 10000 / 10000 / 10000 / 10000
Installation, mounting DIN rail mounting with optional adaptator Connection Type of connection Settings 5600 / 7000 / Range of the magnetic adjustment Magnetic protection nob setting xIN	Termina / 8820 / 10000 / 10000 / 10000 / 4
Connection Type of connection Settings Range of the magnetic adjustment Magnetic protection nob setting xIN	Termina / 8820 / 10000 / 10000 / 10000 / 10000 / 2.5 / 5 / 8
DIN rail mounting with optional adaptator Connection Type of connection Settings Fange of the magnetic adjustment Magnetic protection nob setting xIN Setting type In or Ith	Termina / 8820 / 10000 / 10000 / 10000 / 10000 / 2.5 / 5 / 8
DIN rail mounting with optional adaptator Connection Type of connection Settings Range of the magnetic adjustment	Termina / 8820 / 10000 / 10000 / 10000 / 10000 / 2.5 / 5 / 8 IrTI
DIN rail mounting with optional adaptator Connection Type of connection Settings 5600 / 7000 / Range of the magnetic adjustment Magnetic protection nob setting xIN Setting type In or Ith Equipment Number of auxiliary contacts as normally	Termina / 8820 / 10000 / 10000 / 10000 / 10000 / 2.5 / 5 / 8 IrTI
Connection Type of connection Settings Fange of the magnetic adjustment Magnetic protection nob setting xIN Setting type In or Ith Equipment Number of auxiliary contacts as normally closed contact Number of auxiliary contacts as normally	Termina / 8820 / 10000 / 10000 / 10000 / 10000 / 2.5 / 5 / 8 IrTi
Connection Type of connection Settings Fange of the magnetic adjustment Magnetic protection nob setting xIN Setting type In or Ith Equipment Number of auxiliary contacts as normally closed contact Number of auxiliary contacts as normally open contact Number of auxiliary contacts as change-over contact	Termina / 8820 / 10000 / 10000 / 10000 / 10000 / 2.5 / 5 / 8 IrTI
Connection Type of connection Settings Fange of the magnetic adjustment Magnetic protection nob setting xIN Setting type In or Ith Equipment Number of auxiliary contacts as normally closed contact Number of auxiliary contacts as normally open contact Number of auxiliary contacts as change-over contact Motor drive optional	Termina / 8820 / 10000 / 10000 / 10000 / 10000 / 2.5 / 5 / 8 IrTI
Connection Type of connection Settings Fange of the magnetic adjustment Magnetic protection nob setting xIN Setting type In or Ith Equipment Number of auxiliary contacts as normally closed contact Number of auxiliary contacts as normally open contact Number of auxiliary contacts as change-over contact Motor drive optional Standards	Termina 2 8820 / 10000 / 10000 / 10000 / 10000 2.5 / 5 / 8 IrTi
Connection Type of connection Settings Fange of the magnetic adjustment Magnetic protection nob setting xIN Setting type In or Ith Equipment Number of auxiliary contacts as normally closed contact Number of auxiliary contacts as normally open contact Number of auxiliary contacts as change-over contact Motor drive optional Standards European directive WEEE	Termina 2 8820 / 10000 / 10000 / 10000 / 10000 2.5 / 5 / 8 IrTi
DIN rail mounting with optional adaptator Connection Type of connection Settings 5600 / 7000 / Range of the magnetic adjustment Magnetic protection nob setting xIN Setting type In or Ith Equipment Number of auxiliary contacts as normally closed contact Number of auxiliary contacts as normally open contact Number of auxiliary contacts as change-over contact Motor drive optional Standards European directive WEEE Use conditions	Termina 7 8820 / 10000 / 10000 / 10000 / 10000 2.5 / 5 / 8 IrTl () () Yes
Connection Type of connection Settings 5600 / 7000 / Range of the magnetic adjustment Magnetic protection nob setting xIN Setting type In or Ith Equipment Number of auxiliary contacts as normally closed contact Number of auxiliary contacts as normally open contact Number of auxiliary contacts as change-over contact Motor drive optional Standards European directive WEEE Use conditions Operating temperature	Termina 2 8820 / 10000 / 10000 / 10000 / 2.5 / 5 / 8 1rTh () () () () () () () () () (
Connection Type of connection Settings Fange of the magnetic adjustment Magnetic protection nob setting xIN Setting type In or Ith Equipment Number of auxiliary contacts as normally closed contact Number of auxiliary contacts as normally open contact Number of auxiliary contacts as change-	Termina 7 8820 / 10000 / 10000 / 10000 / 10000 2.5 / 5 / 8 IrTh Concerned -2570 °C 2000 m for all climates