



HED630H

## Moulded Case Circuit Breaker h630 3P 70kA 630A LSI

## **Technical properties**

	_	_		
Λ.	rck	site	cti	ire

Type of order	Toggle
Number of poles	3 P
Type of pole	3P3D
Functions	
Complete device with protection unit	Yes
Trip Unit	LSI
Integrated earth fault protection	No
Configuration	
Number of modules	8
Main electrical features	
Rated operational voltage Ue	220 / 690 V
Frequency	50/60 Hz
Voltage	
Rated insulation voltage	800 V
Rated impulse withstand voltage	8 kV
With under voltage release	No
Electric current	
Rated current	630 A
Rated ultimate short-circuit breaking capacity Icu under 690V AC IEC 60947-2	20 kA
Thermal protection nob setting xIN	0.4 / 0.5 / 0.63 / 0.8 / 0.9 / 0.95 / 1
Breaking capacity on 1 pole for IT 230V NF 60947-2	60 kA
Breaking capacity on 1 pole for IT 400V NF 60947-2	9 kA
Rated service breaking capacity Ics AC according IEC 60947-2	71 %
Rated ultimate short-circuit breaking capacity Icu under 230V AC IEC 60947-2	100 kA
Rated ultimate short-circuit breaking capacity Icu under 240V AC IEC 60947-2	100 kA
Rated ultimate short-circuit breaking capacity Icu under 400V AC IEC 60947-2	70 kA
Rated ultimate short-circuit breaking capacity Icu under 415V AC IEC 60947-2	70 kA
Rated ultimate short-circuit breaking capacity Icu under 440V AC IEC 60947-2	65 kA

Current correction factors	
Correction factor of rating current for 2 devices placed side-by-side	1
Correction factor of rating current for 3 devices placed side-by-side	1
Correction factor of rating current for 4 and 5 devices placed side-by-side	1
Correction factor of rating current for 6 devices placed side-by-side	1
Power	
	120 W
Total power loss under IN	120 W
Power loss per pole at In	40 W
Tripping	
Tripmode	LSI
Thermal protection trip time	5 / 10 / 11 / 16 / 21 ms
Time of response when opening	10 ms
Electrical specifications	
Magnetic trip delay time	100 to 200 ms
Endurance	
Electric endurance in number of cycles	1000
Number of mechanical operations	4000
·	4000
Installation, mounting	
·	4000 No
Installation, mounting	
Installation, mounting  DIN rail mounting with optional adaptator	
Installation, mounting  DIN rail mounting with optional adaptator  Connection	No
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor	No 35 / 240mm²
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable	No 35 / 240mm² 35 / 240mm²
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable  Connection	No  35 / 240mm²  35 / 240mm²  Front connection
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable  Connection  Type of connection  Settings	35 / 240mm <sup>2</sup> 35 / 240mm <sup>2</sup> Front connection  Terminal
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable  Connection  Type of connection  Settings  Range of the magnetic adjustment	35 / 240mm <sup>2</sup> 35 / 240mm <sup>2</sup> Front connection Terminal
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable  Connection  Type of connection  Settings  Range of the magnetic adjustment  Magnetic protection nob setting xIN	35 / 240mm <sup>2</sup> 35 / 240mm <sup>2</sup> Front connection Terminal 3500 / 4410 / 5600 / 6300 / 6300 / 6300 / 6300 A
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable  Connection  Type of connection  Settings  Range of the magnetic adjustment	35 / 240mm <sup>2</sup> 35 / 240mm <sup>2</sup> Front connection Terminal 3500 / 4410 / 5600 / 6300 / 6300 / 6300 / 6300 A
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable  Connection  Type of connection  Settings  Range of the magnetic adjustment  Magnetic protection nob setting xIN	35 / 240mm <sup>2</sup> 35 / 240mm <sup>2</sup> Front connection Terminal 3500 / 4410 / 5600 / 6300 / 6300 / 6300 / 6300 A
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable  Connection  Type of connection  Settings  Range of the magnetic adjustment  Magnetic protection nob setting xIN  Setting type In or Ith	35 / 240mm <sup>2</sup> 35 / 240mm <sup>2</sup> Front connection Terminal 3500 / 4410 / 5600 / 6300 / 6300 / 6300 / 6300 A 2.5 / 5 / 8 IrTh
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable  Connection  Type of connection  Settings  Range of the magnetic adjustment  Magnetic protection nob setting xIN  Setting type In or Ith  Equipment  Number of auxiliary contacts as normally closed contact  Number of auxiliary contacts as normally	35 / 240mm <sup>2</sup> 35 / 240mm <sup>2</sup> Front connection Terminal 3500 / 4410 / 5600 / 6300 / 6300 / 6300 / 6300 A 2.5 / 5 / 8 IrTh
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable  Connection  Type of connection  Settings  Range of the magnetic adjustment  Magnetic protection nob setting xIN  Setting type In or Ith  Equipment  Number of auxiliary contacts as normally closed contact  Number of auxiliary contacts as normally open contact  Number of auxiliary contacts as change-	35 / 240mm <sup>2</sup> 35 / 240mm <sup>2</sup> Front connection Terminal  3500 / 4410 / 5600 / 6300 / 6300 / 6300 / 6300 A  2.5 / 5 / 8  IrTh
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable  Connection  Type of connection  Settings  Range of the magnetic adjustment  Magnetic protection nob setting xIN  Setting type In or Ith  Equipment  Number of auxiliary contacts as normally closed contact  Number of auxiliary contacts as normally open contact  Number of auxiliary contacts as change-over contact	35 / 240mm <sup>2</sup> 35 / 240mm <sup>2</sup> Front connection Terminal  3500 / 4410 / 5600 / 6300 / 6300 / 6300 / 6300 A  2.5 / 5 / 8  IrTh
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable  Connection  Type of connection  Settings  Range of the magnetic adjustment  Magnetic protection nob setting xIN  Setting type In or Ith  Equipment  Number of auxiliary contacts as normally closed contact  Number of auxiliary contacts as normally open contact  Number of auxiliary contacts as change-	35 / 240mm <sup>2</sup> 35 / 240mm <sup>2</sup> Front connection Terminal  3500 / 4410 / 5600 / 6300 / 6300 / 6300 / 6300 A  2.5 / 5 / 8  IrTh
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable  Connection  Type of connection  Settings  Range of the magnetic adjustment  Magnetic protection nob setting xIN  Setting type In or Ith  Equipment  Number of auxiliary contacts as normally closed contact  Number of auxiliary contacts as normally open contact  Number of auxiliary contacts as change-over contact  Motor drive optional  Use cases	No  35 / 240mm²  35 / 240mm²  Front connection  Terminal  3500 / 4410 / 5600 / 6300 / 6300 / 6300 / 6300 / 6300 A  2.5 / 5 / 8  IrTh  0  0  Yes
Installation, mounting  DIN rail mounting with optional adaptator  Connection  Connection cross-sect. flexible conductor  Connection cross-sect. rigid cable  Connection  Type of connection  Settings  Range of the magnetic adjustment  Magnetic protection nob setting xIN  Setting type In or Ith  Equipment  Number of auxiliary contacts as normally closed contact  Number of auxiliary contacts as normally open contact  Number of auxiliary contacts as change-over contact  Motor drive optional	35 / 240mm <sup>2</sup> 35 / 240mm <sup>2</sup> Front connection Terminal  3500 / 4410 / 5600 / 6300 / 6300 / 6300 / 6300 A  2.5 / 5 / 8  IrTh

Standard text IEC 60947-2

## Use conditions

Operating temperature	-2570 °C
Altitude	2000 m
Air humidity protection	for all climates
Storage/transport temperature	-3570 °C